

Instructions and Care Manual for Glass Lids

General Information

Thank you for choosing our glass lid. This lid is designed to enhance your cooking experience with safety and convenience. Please read this manual carefully before using the product.

To ensure long-lasting use of our high-quality glass lid, please consider the following:

- **Before the first use**, remove all original packaging completely.
 - **Caution:** Do not use the product with any packaging parts attached, as this poses a fire hazard.
- Thoroughly clean the product before first use and dry it well.
 - **Caution:** Never use the product uncleaned, as residue or production remnants may be present.

Usage and Safety Instructions

- **Warning: Risk of injury or damage!**
 - The glass lid (including the knob) is oven-safe up to **240°C** (464°F). Do not exceed this temperature to avoid damage.
 - Do not use the lid on open flames, grills, or in microwaves.
 - During use, the lid can become hot. Always use oven mitts or heat-resistant pot holders to prevent burns.
 - Never place the hot lid on cold or wet surfaces, as this may cause thermal shock and cracks.
- **Important Notes on Glass:**
 - Inspect the lid for cracks or damage before each use. Do not use if damaged.
 - Avoid dropping the lid or knocking it against hard surfaces, as glass can break.
- **Caution: Not suitable for children:**
 - Keep the lid out of reach of children. Broken glass can cause serious injuries.

Instructions for Use

1. **Before the first use:**
 - Wash the lid thoroughly with warm water, mild dish soap, and a soft sponge.
 - Dry it completely.
2. **During cooking:**
 - Place the glass lid securely on a pot or pan to cover the food.
 - Ensure the knob is tightly screwed in place. If needed, tighten it by hand (do not overtighten).
3. **Using the lid in the oven:**
 - The lid is safe for temperatures up to **240°C** (464°F).
 - Ensure the lid is completely dry before placing it in the oven.
 - Avoid sudden temperature changes, such as placing the lid in a preheated oven directly from the refrigerator.
4. **After use:**
 - Allow the lid to cool completely before cleaning it.

Cleaning and Maintenance

- The glass lid is dishwasher-safe for gentle cleaning.
- Avoid abrasive cleaners or sharp tools that could damage the surface.
- Store the lid in a safe place to prevent impacts or damage.

Disposal

- Dispose of the lid following local regulations for glass and metal waste.

Manufacturer:

AMT Alumetall-Gießtechnik GmbH, Glörstr. 20-22, D - 58579 Schalksmühle / Germany.

www.bestpan.com / info@gastroguss.de / Tel. + 49 23 55 50 83 - 0.

Responsible Person with reference tot he General Product Safety Regulation (GPSR):

AMT Alumetall-Gießtechnik GmbH, GF Harald Möhl, Glörstr. 20-22, D - 58579 Schalksmühle / Germany.

www.bestpan.com / info@gastroguss.de / Tel. + 49 23 55 50 83 - 0.